

TO ACHIEVE MAXIMUM COVERAGE WITH THE END SLEEVE, THE APPLICATION SHOULD BE CONDUCTED IN THE FOLLOWING MANNER



1

PLACE THE SLOT SIDE OF THE
END SLEEVE OVER THE LONG
LEG OF THE DEAD END



2


DRIVE THE SLEEVE DOWNWARD UNTIL
THE RODS OF THE SHORT LEG ARE
COMPLETELY COVERED



3

THE RODS OF THE LONG LEG
SHOULD BE EVEN WITH, OR
MAY EXTEND ABOVE, THE TOP
EDGE OF THE SLEEVE

BE SURE TO SELECT THE PROPER SIZE END SLEEVE

FILE NO.				
Standard-80				
REVISIONS				
REV	DESCRIPTION	DWN	CHK	APP
3	REDRAWN IN AUTOCAD	JDM	M.F	H.A
DATE: Mar/17/2006				
DWG REFERENCE				
 6718 WEST PLANK ROAD PEORIA, IL 61604 TOLL FREE 800-727-ROHN				
<small>THIS DRAWING IS THE PROPERTY OF ROHN. IT IS NOT TO BE REPRODUCED, COPIED OR TRACED IN WHOLE OR IN PART WITHOUT OUR WRITTEN CONSENT.</small>				
SPLICE CONNECTION FOR BIG GRIP & END SLEEVE				
DWN:	H.A	CHK'D:	RAM	DATE:
				Jun/09/1970
ENGR:				
TWS				
DRAWING NO:				REV:
B700607				3