

"F"



NF-1
Push-on Male to
Female Adapter.
Adaptador a Presión Macho a Hembra.



NF-7
Push-on Connector for RG-59.
Conector a Presión para RG-59.



NF-6
NF-6G (gold)
Twist-on Connector for RG-59.
Conector de Rosca para RG-59.



NF-56
NF-56G (gold)
Twist-on Connector for RG-6.
Conector de Rosca para RG-6.



NF-18
Twist-on Angled Male to
Female Adapter.
Adaptador en ángulo de
Rosca Macho a Hembra



F-71
All Channel Terminator,
75 Ohms.
Terminación para Todos
los Canales, 75 Ohms.



F-71B
Twist-on Male to
Male Adapter.
Adaptador de Rosca
Macho a Macho.



NF-3
Female to RCA
Female Adapter.
Adaptador Hembra a Hembra RCA.



NF-4
Female to RCA
Male Adapter.
Adaptador Hembra a Macho RCA.



NF-35
Male to RCA
Female Adapter.
Adaptador Macho a Hembra RCA.



F-91
Female Crimp for RG-59.
Hembra para RG-59.



F-96
Female Crimp for RG-56.
Hembra para RG-56.