


WMP


VIDEO MOUNT PRODUCTS

Instruction Sheet For:


W-13B, W-13W & W-13S




*For more information, please contact us at:
325 Log Canoe Circle, Stevensville, Maryland 21666
(T) 410.643.6390 / (F) 410.643.6615
www.videomount.com*



Step 2: Attaching the wall plate to the wall (Lag screws are not included)



Step 3: Attaching the support tube



Step 4: Attaching the plastic connector

Step 1

Before starting, lay out all parts to your mount and match them to the parts list provided. Verify that you have all your parts before attempting to assemble the mount.

Step 2

Mark wall or desired mounting surface in preparation of installation of the wall plate (3) to desired surface. Pre-drill, if necessary, and mount wall plate (3) to desired surface. Make sure the wall plate (3) is secure on the mounting surface. Note: Make sure the smaller hole on the wall plate's flanges is mounted upwards and the larger hole downwards as shown in picture. **Warning: Please verify that your mounting surface will support the combined weight of your mount, mounting hardware, and monitor. Also verify that the mounting surface is safe to drill through. If in doubt, please contact a professional installer.**

Step 3

Insert the support tube (2) into the wall plate (3) from the bottom up. Insert the plastic washer (12) between the between the top of the support tube (2) and the wall plate flange (3). Use a washer (11) and nylon nut (5) to secure the support tube (2) to the top of the wall plate (3).

Step 4


Place the plastic connector (6) on the end of the support tube (2) and use the M5 screw (9) to secure the connector to the support tube.

Step 5

Insert the 5/16" screw (13) into the bottom of the support tube (2). Slide the 5/16" screw through the slot in the center of the circular depression in the middle of the platform (1). Use a washer (4) and nylon nut (10) to attach the platform to the plastic connector.

Step 6

Snap the plastic swivel (7) onto the plastic connector (6) and plastic cover (8) onto the wall plate (3). Next place your TV onto the platform and use the safety strap (14) by inserting the end without the grip through the slot on either side of the platform (1) going over your TV through the other slot in the platform and wrapping under the platform and cinching the strap tight.



Step 5 : Attaching the platform to the plastic connector

Enjoy Your Mount!

WARNING: The installer of these products must verify that the mounting surface, ceiling or wall, will safely support the combined weight of all attached equipment and hardware. Video Mount products will not be held liable for the improper use or installation of its products.